



VOYAGER RACKS dot com

Made for: 1994-2004 Land Rover Discovery Series I and II
Part No: VOYD12VR (Low Pro, Standard, ORC, Campers, Overland)

Thank you for your recent purchase!

- Step 1: Remove packaging
- Step 2: Lift and center your new Voyager Rack onto vehicle, set into gutter
- Step 3: Install provided hardware as seen in illustrations

INCLUDED:

Standard, Low Pro Voyager Racks ONLY

- 8 Gutter Brackets
- 16 5/16x3/4 Bolts, 16 Washers

Overland/Offroad Challenge Racks ONLY

- 8 5/16 x .75Bolts, 16 Washers
- 16 5/16 x 1/.25 Bolts, 48 Washers
- 24 Lock-Nuts
- 4 Shovel/Axe KWIK-FIST Mounts (Nuts, Bolts, Washers to install to passenger side of rack)
- Hi-Lift Jack Hardware to Bolt to Driver Side of Rack, Holds Hi-Lift (2 Long 1/2" Bolts, 4 washers, Coupling Nuts/Spacers, Washers, Wingnuts)

Standard/Low Profile



Standard/Low Profile



Overland/Offroad Challenge



Overland/Offroad Challenge



If you have any questions, or need assistance, please email SALES@VOYAGEROFFROAD.COM or call/text:

+1 844-NAS-RACK

Thank you for your purchase!

-Voyager