



VOYAGER RACKS dot com

Made for: Land Rover

Model: Fits Range Rover EVOQUE

Part No: VOYEVOQUEG1 (Low Pro, ORC)

Thank you for your recent purchase!

The following is needed to install your new Voyager Rack:

Box knife

Plastic Pry-Tool/Plastic Cats Paw

$\frac{3}{4}$ " Wrench/ Ratchet and Socket

$\frac{1}{2}$ Drill bit for trim modification (not required)

- INCLUDED

4 Threaded Stantions

4- $\frac{1}{2}$ "x $1\frac{1}{4}$ Bolts

8- Fender/Flat Washers



Step 1: Locate and Remove trim above 4 corner install positions. If installed; Remove stock rubber/aluminum rails, add $\frac{1}{2}$ hole if needed to allow stock plastic trim to slide over provided Stantions. **TIP:** Install rack and center, tighten roof hardware, remove rack, then hold corresponding roof trim over stantion, drill hole in trim. **NOTE: CURVED STANTION GOES IN FRONT OF RACK**

Step 2: Center rack on hardware, loosely start hardware

Step 3: Quickly add a bolt with washer on top and bottom of rack hardware, repeat.

Step 4: Center Rack, Snug Bolts until rack does not move, and no air gap can be seen between hardware and rack.



If you have any questions, or need assistance, please email SALES@VOYAGEROFFROAD.COM or call/text:

+1 844-NAS-RACK

Thank you for your purchase!

-Voyager

SAFETY TIP: CHECK YOUR HARDWARE AFTER EACH VOYAGE.